




3



4




5



- Loosen the knobs before adjusting height of desk.
 - Adjust height of desk to which you'd like, then tighten the knobs.
- Note:** Do not adjust height of desk after tightening the knobs.

mi MOUNT-IT!


MI-10204




VISIT US AT MOUNT-IT.COM FOR PRODUCT REGISTRATION AND WARRANTY INFORMATION.
CONTACT US AT SUPPORT@MOUNT-IT.COM OR 855-925-5668 FOR QUESTIONS OR COMMENTS.

Children Adjustable Desk


ASSEMBLY INSTRUCTIONS



B1



B2



B3



B4



B5x2



A1x10







A2x10






A3x1

1



2



CAUTION!

1. This product is intended for indoor use only.
2. This product should be placed on the flat ground.
3. Once water, oil and other liquid adhere to the surface of product, you should quickly wipe it clean.
4. Please regularly check and fasten joint parts in case of product shake and loosening.
5. Do not lay product in place of the corrosive gas and moisture in case of surface damage.
6. Never fasten screws tightly before all screws fixed to the right place.
7. Please use damp cloth to clean the desktop.