




Please scan this QR code
to visit the product page

L-Shaped Sit Stand Desk



HAVE QUESTIONS?

Monday - Friday from 8:00am - 4:00pm PST



support@mount-it.com



(855) 925-5668



www.mount-it.com

Thank you for choosing Mount-It!

EN  Read the entire instruction manual before you start installation and assembly. If you have any questions regarding any of the instructions or warnings, please contact Mount-It! for assistance.

 **CAUTION:** Use with products heavier than the rated weights indicated may result in instability causing possible injury.

- Please closely follow the assembly instructions. Improper installation may result in damage or serious personal injury.
- This product contains small items that could be a choking hazard if swallowed. Keep these items away from children.

IMPORTANT: Ensure that you have received all parts according to the component checklist prior to installation. If any parts are missing or faulty, contact Mount-It! for a replacement.

MAINTENANCE: Check that the product is secure and safe to use at regular intervals (at least every three months).

DE  Lesen Sie die gesamte Bedienungsanleitung, bevor Sie mit der Installation und Montage beginnen. Wenn Sie Fragen zur Anleitung oder Warnungen haben, wenden Sie sich bitte an Ihren örtlichen Händler.

 **VORSICHT:** Die Verwendung mit Produkten, die schwerer als die angegebenen Nenngewichte sind, kann zu Instabilität führen und zu möglichen Verletzungen führen.

- Bitte befolgen Sie die Montageanleitung genau. Eine unsachgemäße Installation kann zu Schäden oder schweren Verletzungen führen.
- Dieses Produkt enthält Kleinteile, die beim Verschlucken eine Erstickenungsgefahr darstellen können. Halten Sie diese Gegenstände von Kindern fern.

WICHTIG: Stellen Sie vor der Installation sicher, dass Sie alle Teile gemäß der Komponenten-Checkliste erhalten haben. Bei beschädigten oder fehlenden Teilen, wenden Sie sich an Ihre Verkaufsstelle, um Ersatz zu erhalten.

WARTUNG: Überprüfen Sie das Produkt in regelmäßigen Abständen auf Sicherheit und Stabilität (am besten alle drei Monate).

FR  Lisez entièrement le guide d'utilisateur avant de commencer l'installation et le montage. Si vous avez des questions concernant les instructions ou les avertissements, veuillez contacter votre distributeur local pour une assistance.

 **ATTENTION:** L'utilisation de produits plus lourds que les poids nominaux indiqués peut entraîner une instabilité causant des blessures potentielles.

- Les supports doivent être joints comme spécifié dans les instructions de montage. Une mauvaise installation peut entraîner des dommages ou de graves blessures aux personnes.
- Ce produit contient de petites pièces qui peuvent causer un étouffement si elles sont avalées. Éloignez ces pièces des enfants.

IMPORTANT: Avant l'installation, assurez-vous que vous avez reçu toutes les pièces selon la liste de vérification des composants. Si une pièce est manquante ou endommagée, téléphonez à votre distributeur local pour qu'il la remplace.

MAINTENANCE: A intervalles réguliers (au moins tous les trois mois) vérifiez que le support est d'utilisation sûre et fiable.

RU  Перед началом установки и сборки прочитайте руководство по установке. Если у Вас возникли какие-либо вопросы относительно инструкций или предупреждений, свяжитесь с Вашим локальным распространителем для получения помощи.

 **Внимание:** Использование продуктов, вес которых превышает указанный расчетный вес, может привести к неустойчивости и возможному травмированию.

- Опоры должны быть установлены, как это показано в Монтажных инструкциях. Неправильная установка может привести к получению серьезных травм.
- Данный продукт содержит маленькие детали, которые представляют опасность удушья при проглатывании. Такие детали необходимо хранить в недоступном для детей месте.

ВАЖНО: Перед установкой убедитесь, что Вы получили все детали в соответствии со списком комплектующих. Если не хватает каких-либо деталей или они поломаны, свяжитесь с Вашим местным распространителем по вопросу замены.

ТЕХНИЧЕСКОЕ ОБСЛУЖИВАНИЕ: Необходимо регулярно проверять (как минимум, раз в три месяца), чтобы кронштейн был зафиксирован, и его использование было безопасным.

ES  Lea todo el manual de instrucciones antes de comenzar la instalación y ensamble de la unidad. Si tiene alguna inquietud con respecto a las instrucciones o advertencias, comuníquese con su distribuidor local.

 **PRECAUCION:** utilizar con productos de mayor peso al indicado en los límites de peso podría ocasionar inestabilidad y posibles heridas personales.

- Los soportes deben acoplarse tal como se indica en las instrucciones de ensamble. Una incorrecta instalación podría ocasionar daños y serias heridas personales.
- Este producto contiene piezas pequeñas que representan un riesgo de asfixia. Mantenga estas piezas fuera del alcance de los niños.

IMPORTANTE: Asegúrese de que haya recibido todas las piezas según la lista de verificación de componentes para la instalación. Si falta alguna de las partes, o está dañada, comuníquese con su distribuidor.

MANTENIMIENTO: Compruebe periódicamente que el soporte esté asegurado y listo para usar (al menos cada tres meses).

PT  Leia todo o manual de instruções antes de iniciar a instalação e montagem. Se você tiver alguma dúvida sobre quaisquer uma das instruções ou avisos, por favor, entre em contato com o seu distribuidor local para assistência.

 **ATENÇÃO:** O uso com produtos mais pesados do que os pesos indicados pode resultar em instabilidade, causando possíveis danos.

- Os suportes devem ser anexados como especificado nas instruções de montagem. A instalação incorreta pode causar danos ou sérias lesões pessoais.
- Este produto contém pequenas peças que podem causar asfixia se ingeridas. Mantenha esses itens longe do alcance de crianças.

IMPORTANTE: Assegure-se que você recebeu todas as peças, de acordo com a lista de componentes, antes da instalação. Se alguma peça estiver faltando ou é defeituosa, contate o seu distribuidor local para substituição.

MANUTENÇÃO: Certifique-se que o suporte seja seguro e protegido para o uso em intervalos regulares (pelo menos a cada três meses).

USING THE CONTROLLER

Please retain these instructions for future reference

	Short-press the [S] button, and the display will flash. Press the  ,  , or  button to save the current height setting to that button.
	Press the  button, and the desk will move to the height that was previously set for that button.
	Press the  button, and the desk will move to the height that was previously set for that button.
	Press the  button, and the desk will move to the height that was previously set for that button.
	Press the  button to raise the desk continuously until it reaches the highest position of 47.2 " (120cm) or the button is released.
	Press the  button to lower the desk continuously until it reaches the lowest position of 28.3" (72cm) or the button is released.

Settings

Change Display Height Units	Press and hold the  button until a flashing 'S-' is displayed. Press  again, and 'Un' is displayed. Press  to select it, press  or  to switch between 'IN' (imperial) and 'SI' (metric), and press  to save your choice.
Change Collision Detection Sensitivity	Press and hold the  button until a flashing 'S-' is displayed. Press  again, and 'Un' is displayed. Press  or  to switch to 'CF' and press  to select it. Press  or  to switch between off, low, normal, and high sensitivity. Press  to save your choice.
Reset	Press and hold the  button for 5 seconds, and the screen will show 'RES.' Continue holding until the desk goes down to its lowest level and comes back up slightly.

Protection Mode Error Codes

Hot	Overheating Protection: When the motor has been working continuously for 2 minutes, it will stop operating to prevent damage from overheating. Wait for at least 18 minutes before making any further height adjustment.
E10	Sensor Malfunction Warning: Motor safety sensor can't be detected. Power off, check the connection between the motor and controller, and power back on again.
E20	Overloading Warning: Max load exceeded. If raising the desk, remove objects from the desk to reduce weight and try again. If lowering the desk, power off, take the things off the desk, power back on, and try again.
E02	Operation Status Warning: The desk stops moving if vibration, impact, or incline are detected. If this detection is incorrect, follow the reset instructions before continuing use.
E32	Overvoltage Protection: Input voltage too high. If the correct AC adapter is being used, power off the desk, check the connection between power and the controller, and power on again.
E31	Undervoltage Protection: Input voltage too low. If the correct AC adapter is being used, power off the desk, check the connection between power and the controller, and power on again.
E60	Unequal Leg Height Warning: Power off the desk and check whether the left and right legs are at the same height. Adjust if necessary by following the instructions. Power on again.
-	Cable Disconnection Warning: Check motor and controller cable connections. Normal operation should return once all connectors are properly connected.

PACKAGE CONTENTS



A (x1)
DESKTOP




B (x1)
DESKTOP




C (x1)
LONG SIDE PLATE



D (x1)
SHORT SIDE PLATE



E (x2)
LEGS



F (x1)
CROSSBAR




G (x1)
CROSSBAR



H (x2)
CONNECTOR



I (x1)
CROSSBAR



J (x1)
CROSSBAR



K (x1)
LONG FOOT




L (x1)
SHORT FOOT



M (x2)
CLOTH DRAWER BRACKETS



N (x1)
CLOTH DRAWER




O (x1)
CABLE HOLDER



P (x1)
TEMPLATE



Q (x1)
CONTROL PANEL



R (x1)
POWER ADAPTER



S (x1)
MOTOR CONNECTION CABLE

HARDWARE CONTENTS



a (x32)
M5x16 SCREW



b (x24)
M6x11 BOLT




c (x2)
M3.5x19 SCREW



d (x8)
M6x10 BOLT



e (x1)
5mm
HEX WRENCH



f (x1)
4mm
HEX WRENCH



g (x5)
CABLE MANAGEMENT CLIP



h (x2)
TABLETOP CONNECTORS



i (x12)
RUBBER PADS



j (x2)
HEADPHONE HOOKS



k (x3)
WOOD DOWELS

EXTRA PARTS



a (x2)
M5x16 SCREW



b (x2)
M6x11 BOLT



d (x2)
M6x10 BOLT



k (x1)
WOOD DOWELS



i (x2)
RUBBER PADS


Step 1

Assembling the Leg Sections

1-1 Assemble the Feet

Attach the Short Foot (#L) to one Leg (#E), using Bolts (#b) and tighten until secure using the 5mm Hex Wrench (#e).

Attach the Long Foot (#K) to the other Leg (#E), using Bolts (#b) and tighten until secure using the 5mm Hex Wrench (#e).




1-2 Assembling the Side Plates

Attach the Short Side Plate (#D) to the Leg (#E) with Short Foot (#L) using Bolts (#d).

Attach the Long Side Plate (#C) to the Leg (#E) with Long Foot (#K) using Bolts (#d).


Ensure that the Side Plates are oriented as shown in the image.



1-3 Assembling the Long Crossbar

As shown in magnification bubble1, tighten the Bolts (#d) using 4mm Hex Wrench (#f)


As shown in magnification bubble2, attach the Crossbar (#F and #G) to the leg with Long Foot using the Bolts (#b) and tighten until secure using the 5mm Hex Wrench (#e).



1-4 Assembling the Short Crossbar

As shown in magnification bubble1, tighten the Bolts (#d) using 4mm Hex Wrench (#f)

As shown in magnification bubble2, attach the Crossbar (#I and #J) to the leg with Short Foot using the Bolts (#b) and tighten until secure using the 5mm Hex Wrench (#e).




Step 2

Assembling the Legs and Crossbar


2-1 Attach the Connector

Attach the Connector (#H) to the left and right Crossbars as shown in the image, using Bolts (#b) and tighten until secure using the 5mm Hex Wrench (#e).




2-2 Attach the Rubber Pad

Attach the Rubber Pads (#i) to the top of the Frame in the locations shown here. All 12 pads will be used.




2-1 Attach the Connector

Attach the Connector (#H) to the left and right Crossbars as shown in the image, using Bolts (#b) and tighten until secure using the 5mm Hex Wrench (#e).



2-2 Attach the Rubber Pad

Attach the Rubber Pads (#i) to the top of the Frame in the locations shown here. All 12 pads will be used.




Step 3

Assembling the Desktop

3-1 Mark the Locations for the Screws (Control Panel on the Left)

Lay the Desktop (#A) piece out in the configuration shown below. Position the Template (#P) on the Desktop and use a pencil to mark all the locations for the screws through the template.


CAUTION: Before marking or installing screws ensure your desk frame has been assembled according to Option A so that the control panel will be on the left-hand side after assembly.



**Option A: Desk Corner
Panel will be on your left**

3-2 Assemble the Desktop together


Lay the Desktop (#A, B) pieces out upside-down in the configuration shown below. Place the Wood Dowels (#k) into the holes on the edge of the desktop pieces and press the boards together over each end of the dowels. Use the Tabletop Connectors (#h) in the locations shown and secure in place using Screws (#a). Tighten until secure.



3-1 Mark the Locations for the Screws (Control Panel on the Right)

Lay the Desktop (#A) piece out in the configuration shown below. Position the Template (#P) on the Desktop and use a pencil to mark all the locations for the screws through the template.


CAUTION: Before marking or installing screws ensure your desk frame has been assembled according to Option A so that the control panel will be on the left-hand side after assembly.



Option B: Desk Corner Panel will be on your right

3-2 Assemble the Desktop together


Lay the Desktop (#A, B) pieces out upside-down in the configuration shown below. Place the Wood Dowels (#k) into the holes on the edge of the desktop pieces and press the boards together over each end of the dowels. Use the Tabletop Connectors (#h) in the locations shown and secure in place using Screws (#a). Tighten until secure.




Step 4

Attaching the Frame to the Desktop

Turn the leg frames over and carefully place it upside down on the desktop. Align the holes on the frame with the holes on the tabletop. Attach the Desk Frame to the Desktop using Screws (#a). Tighten until secure.



**Option A: Desk Corner
Panel will be on your left**




**Option B: Desk Corner
Panel will be on your right**

Step 5


Fold the Cable Holder and Cloth Drawer Brackets

Fold the Cable Holder and Cloth Drawer Brackets into the shape shown in the image. Fold with care, do not fold and unfold. If needed use the edge of a table or other solid edge to assist with folding them.

Cable Holder



Cloth Drawer Brackets




Step 6

Assembling the Cable Holder / Headphone Hook / Controller and Cloth Drawer Brackets

Using Screws (#c) attach the Control Panel (#Q) to the locations shown.
Using Screws (#a) attach the Headphone Hooks (#j) to the locations shown.
Attach the Cloth Drawer Brackets (#M) as shown so that they face each other, then attach the Cable Holder (#O). Ensure the Drawer brackets are installed on the outer set of holes as shown below.





**Option A: Desk Corner
Panel will be on your left**



Using Screws (#c) attach the Control Panel (#Q) to the locations shown. Using Screws (#a) attach the Headphone Hooks (#j) to the locations shown. Attach the Cloth Drawer Brackets (#M) as shown so that they face each other, then attach the Cable Holder (#O). Ensure the Drawer brackets are installed on the outer set of holes as shown below.



**Option B: Desk Corner
Panel will be on your right**



Step 7

Connect the Power Lines and Attach the Cable Clips





Connect the Power Lines

Connect the Power Lines as shown in the image.

Attach the Cable Clips

Attach the Cable Clips (#g) to the underside of the desktop as needed. It is recommended that they be placed approximately in the middle of each length of wire to prevent the cords from hanging too low. Open the Cable Clip as shown in the magnification bubbles, insert the cord and close the clip again.

**Option A: Desk Corner
Panel will be on your left**




Connect the Power Lines

Connect the Power Lines as shown in the image.

Attach the Cable Clips

Attach the Cable Clips (#g) to the underside of the desktop as needed. It is recommended that they be placed approximately in the middle of each length of wire to prevent the cords from hanging too low. Open the Cable Clip as shown in the magnification bubbles, insert the cord and close the clip again.



**Option B: Desk Corner
Panel will be on your right**




Step 8

Insert the Cloth Drawer

Insert the Cloth Drawer (#N) into the Brackets (#M)



Connect the Power



Warnings




Do not exceed desk weight limit.



Keep area of vertical motion free of obstacles.



Keep weight on desk balanced for correct operation and longer life of components.



Leave enough slack in cables to allow for full range of vertical motion.

Visit us at **www.mount-it.com** for product registration and warranty information.

Our US based customer service team is standing by to answer any questions you have about your Mount-It! product.

Available by phone **Monday - Friday from 8:00am to 4:00pm PST.**

Chat live with an agent on our website!



support@mount-it.com



(855) 925-5668



www.mount-it.com

