




Heavy Duty Dual TV Ceiling Mount



HAVE QUESTIONS?

Monday - Friday from 5:00am - 5:00pm PST



support@mount-it.com



(855) 925-5668



www.mount-it.com

Thank you for choosing Mount-It!!

EN Read the entire instruction manual before you start installation and assembly. If you have any questions regarding any of the instructions or warnings, please contact Mount-It! for assistance.

CAUTION: Use with products heavier than the rated weights indicated may result in instability causing possible injury.

- Mounts must be attached as specified in assembly instructions. Improper installation may result in damage or serious personal injury.
- Safety gear and proper tools must be used. This product should only be installed by professionals.
- Make sure that the supporting surface will safely support the combined weight of the equipment and all attached hardware and components.
- Use the mounting screws provided and DO NOT OVER TIGHTEN mounting screws.
- This product contains small items that could be a choking hazard if swallowed. Keep these items away from children.
- This product is intended for indoor use only. Using this product outdoors could lead to product failure and personal injury.

IMPORTANT: Ensure that you have received all parts according to the component checklist prior to installation. If any parts are missing or faulty, telephone Mount-It! for a replacement.

MAINTENANCE: Check that the bracket is secure and safe to use at regular intervals (at least every three months).

DE Bitte vor Beginn der Montage und Zusammenbau das ganze Handbuch durchlesen. Bitte sich mit dem Händler vor Ort bei Fragen zur Anleitung oder Warnungen in Verbindung setzen.

VORSICHT: Bei Verwendung mit Produkten, die das zulässige Gewicht überschreiten, können Schäden oder möglicherweise Verletzungen die Folge sein.

- Halterungen sollen entsprechend den Montageanweisungen angebracht werden. Eine unsachgemäße Montage kann Schäden oder Verletzungen zur Folge haben.
- Sicherheitsausrüstung und geeignete Werkzeuge verwenden. Die Montage des Produktes sollte nur von Fachleuten durchgeführt werden.
- Die tragenden Oberflächen sollten das gesamte Gewicht von Geräten und allen zusätzlichen Bauteilen sicher aushalten können.
- Nur die mitgelieferten Einbaueisen und die Schrauben NICHT ZU FEST ANZIEHEN.
- Dieses Produkt enthält Kleinteile, die Erstickungsgefahr beim Verschlucken hervorrufen können. Diese Teile von Kindern fernhalten.
- Dieses Produkt nur in Innenräumen verwenden. Verwendung des Produktes im Außenbereich kann zu Verletzungen und Schäden führen.

WICHTIG: Vor der Montage bitte alle erhaltenen Bauteile mit der Bauteilliste abgleichen. Bei beschädigten oder fehlenden Teilen den Händler vor Ort nach Ersatzteilen fragen.

WARTUNG: Die Halterungsklammer regelmäßig auf Sicherheit und Stabilität prüfen (am besten alle drei Monate).

FR Lisez entièrement le guide d'utilisateur avant de commencer l'installation et le montage. Si vous avez des questions concernant les instructions ou les avertissements, veuillez contacter votre distributeur local pour une assistance.

ATTENTION: L'utilisation de produits plus lourds que les poids nominaux indiqués peut entraîner une instabilité causant des blessures potentielles.

- Les supports doivent être joints comme spécifié dans les instructions de montage. Une mauvaise installation peut entraîner des dommages ou de graves blessures aux personnes.
- Un équipement de sécurité et les outils appropriés doivent être utilisés. Ce produit devrait être installé uniquement par des professionnels.
- Assurez-vous que la surface de soutien supporte en sécurité le poids combiné de l'équipement et de tous les matériaux et composants associés.
- Utilisez les vis de montage fournies et NE SÉRREZ PAS TROP les vis de montage.
- Ce produit contient de petites pièces qui peuvent causer un étouffement si elles sont avalées. Éloignez ces pièces des enfants.
- Ce produit est prévu uniquement pour une utilisation à l'intérieur. L'utilisation de ce produit à l'extérieur peut entraîner une défaillance du produit ou des blessures aux personnes.

IMPORTANT: Avant l'installation, assurez-vous que vous avez reçu toutes les pièces selon la liste de vérification des composants. Si une pièce est manquante ou endommagée, téléphonez à votre distributeur local pour qu'il la remplace.

MAINTENANCE: A intervalles réguliers (au moins tous les trois mois) vérifiez que le support est d'utilisation sûre et fiable.

RU Перед началом установки и сборки прочитайте руководство по установке. Если у Вас возникли какие-либо вопросы относительно инструкции или предупреждений, свяжитесь с Вашим локальным распространителем для получения помощи.

ВНИМАНИЕ: Использование продуктов, вес которых превышает указанный расчетный вес, может привести к неустойчивости и возможным повреждениям.

- Опоры должны быть установлены, как это показано в монтажных инструкциях. Неправильная установка может привести к получению серьезных травм.
- Необходимо использовать предохранительное устройство и специальные инструменты. Продукт должен устанавливаться только профессионалами.
- Убедитесь, что несущая поверхность выдержит вес оборудования и всего установленного оборудования и комплектующих.
- Необходимо использовать шурупы в комплекте установочные шурупы и НЕ ПЕРЕТЯГИВАТЬ установочные шурупы.
- Данный продукт содержит мелкие детали, которые представляют опасность удушья при проглатывании. Такие детали необходимо хранить в недоступном для детей месте.
- Данный продукт предназначен только для эксплуатации в помещениях. Использование данного продукта на улице может привести к поломке продукта и получению травм.

ВАЖНО: Перед установкой убедитесь, что Вы получили все детали в соответствии со списком комплектующих. Если не хватает каких-либо деталей или они поломаны, свяжитесь с Вашим местным распространителем по адресу замены.

ТЕХНИЧЕСКОЕ ОБСЛУЖИВАНИЕ: Необходимо регулярно проверять (как минимум, раз в три месяца), чтобы кронштейн был зафиксирован, и его использование было безопасным.

ES Lea todo el manual de instrucciones antes de comenzar la instalación y ensamble de la unidad. Si tiene alguna inquietud con respecto a las instrucciones o advertencias, comuníquese con su distribuidor local.

PRECAUCIÓN: utilizar con productos de mayor peso al indicado en los límites de peso podría ocasionar inestabilidad y posibles heridas personales.

- Los soportes deben acoplarse tal como se indica en las instrucciones de ensamble. Una incorrecta instalación podría ocasionar daños y serias heridas personales.
- Utilice las herramientas y equipo de seguridad adecuados. Este producto solo debe ser instalado por profesionales.
- Asegúrese de que la superficie de fijación sostenga de manera segura el peso total del equipo y todos sus componentes y hardware.
- Utilice los tornillos de ensamble suministrados y NO aplique demasiada tensión a los tornillos.
- Este producto contiene piezas pequeñas que representan un riesgo de asfixia. Mantenga estas piezas fuera del alcance de los niños.
- Este producto está diseñado para uso en interiores solamente. Utilizar este producto en exteriores podría ocasionar fallos y heridas personales.

IMPORTANTE: Asegúrese de que haya recibido todas las piezas según la lista de verificación de componentes para la instalación. Si falta alguna de las partes, o está dañada, comuníquese con su distribuidor.

MANUTENIMIENTO: Compruebe periódicamente que el soporte esté asegurado y listo para usar (al menos cada tres meses).

PT Leia todo o manual de instruções antes de iniciar a instalação e montagem. Se você tiver alguma dúvida sobre quaisquer uma das instruções ou avisos, por favor, entre em contato seu distribuidor local para assistência.

ATENÇÃO: O uso com produtos mais pesados do que os pesos indicados pode resultar em instabilidade, causando possíveis danos.

- Os suportes devem ser anexados como especificado nas instruções de montagem. A instalação incorreta pode causar danos ou sérias lesões pessoais.
- Equipamentos de segurança e ferramentas adequadas devem ser utilizadas. Este produto só deve ser instalado por profissionais.
- Certifique-se que a superfície de suporte suportará com segurança o peso combinado do equipamento e todas as ferragens e componentes anexados.
- Use os parafusos de montagem fornecidos e NÃO APERTE EXCESSIVAMENTE os mesmos.
- Este produto contém pequenas peças que podem causar asfixia se ingeridas. Mantenha esses itens longe do alcance de crianças.
- Este produto destina-se somente para uso interno. Usá-lo em ambiente externo pode causar falhas no produto e lesões pessoais.

IMPORTANTE: Assure-se que você recebeu todas as peças, de acordo com a lista de componentes, antes da instalação. Se alguma peça estiver faltando ou é defeituosa, contate o seu distribuidor local para substituição.


MANUTENÇÃO: Certifique-se que o suporte seja seguro e protegido para o uso em intervalos regulares (pelo menos a cada três meses).

COMPATIBLE VESA SIZES
200x200 300x300
400x200 400x400
600x400


COMPATIBLE WITH
Screens UP TO
70" MAX

45kgx2
(99lbs)x2
RATED


PACKAGE CONTENTS



TV MOUNTING HARDWARE



CEILING MOUNTING HARDWARE




Check carefully to make sure there are no missing or defective parts. Some hardware provided may not be used. Use the correct wall mounting and monitor mounting hardware suitable for your installation.

CHOKING HAZARD. Package includes small parts.
Not for children under 3 years. Adult supervision is required.

Missing Parts? Call us at (855) 925-5668 and we will ship replacement parts free of charge.

Dimension and Weight Capacity



Rated weight capacity is 99 lbs (45kgs)/screen.

Caution:




**DO NOT EXCEED MAXIMUM LISTED WEIGHT CAPACITY.
SERIOUS INJURY OR PROPERTY DAMAGE MAY OCCUR.**

Step 1a

Mounting to a Wood Stud or Joist

- Using a stud finder locate the center of the ceiling joist or angled wall stud. Center the Mounting Template (#J) on the stud and mark the center of the holes with a pencil.
- Drill pilot holes on the marked locations using a 3/16" drill bit to a depth of 2.2". Attach Ceiling Bracket (#A) to the drilled holes using Lag Screws (#W-A) and Washers (#W-C) and tighten until secure.
- Allow the pole to hang freely downward and then tighten the lower nut and bolt on the bracket (pictured below) by tightening the nut clockwise with Wrench (#H), holding the bolt in place on the other end with Allen Wrench (#I).

Note: In addition to normal ceiling mounting, this product may be mounted to angled ceiling surfaces or to the side of an exposed joist at a maximum of a 90° angle.




Step 1b

Mounting to Concrete or Brick

- Place the mounting template in the desired location and mark the center of the holes with a pencil.
- Drill holes on the marked locations using a 1/2" drill bit to a depth of 1.8". Clear dust and debris from the hole. Insert Concrete Anchors (#W-B) into the holes and remove the nut, lock washer, and washer from the end. Place the Ceiling Bracket (#A) over the protruding ends of the anchors and replace the removed pieces in order (Washer, lock washer, then nut) and tighten the nuts until secure.
- Allow the pole to hang freely downward and then tighten the lower nut and bolt on the bracket (pictured below) by tightening the nut clockwise with Wrench (#H), holding the bolt in place on the other end with Allen Wrench (#I).


Note: Do not drill mounting holes into mortar (such as between bricks or stones) only drill and install into solid stone or concrete surfaces.



Step 2

Routing Cables and Installing the Lower Pole


- Slide the Swivel Bracket (#C) over the Lower Pole (#B) until it rests at the bottom.
- Route the TV cables as shown through the upper and lower poles. Insert the lower pole inside the upper portion and position at the desired height. Secure the pole in place using Height Adjustment Bolts (#G) and Nuts (#F).



Step 3

Attaching the Horizontal Arm to the Mount


- Remove the nuts (pictured in the magnification bubble below) on the inside of the Horizontal Arms (#E). Hang the Horizontal Arms onto the corresponding slots on the end of the Lower Pole (#B). Reattach the nuts and tighten until secure. $\pm 3^\circ$ level adjustment is controlled by these upper bolts and nuts, use a bubble level to verify the arms are even.



Step 4

Removing the Security Screw



- Remove the security screw pictured below from each of the VESA Arms (#D).



Step 5a

Attaching the VESA Arms to the TV (No Spacers)





- Spacers will not be required if the VESA bolts used are the correct length that matches the depth of the TV VESA holes.
- Select the appropriate size mounting bolt (#M-A or M-B) for your display's mounting holes and verify the length of the VESA bolt is not too long. If you are unsure of the correct bolt size for your display refer to your TV user manual or contact the TV manufacturer for sizing information.



Step 5b

Attaching the VESA Arms to the TV (With Spacers)

- Spacers will be required if the VESA bolts used are too long for the depth of the TV VESA holes. Spacers are provided to adjust the length of the mounting bolt.
- Select the appropriate size mounting bolt (#M-C or M-D) for your display's mounting holes and verify the length of the VESA bolt is not too long. If you are unsure of the correct bolt size for your display refer to your TV user manual or contact the TV manufacturer for sizing information. If necessary, use the included spacers (#M-F, M-G) between the mount and the TV as shown below to adjust the length of the mounting bolt. Multiple spacers can be used in combination to achieve the desired bolt depth.





Step 6

Final Adjustments

- Hang the TV on the horizontal arm as shown so that the full weight of the screen is being supported by the VESA arms. Note: It is recommended that at least two persons assist during this step.
- Re-insert the security bolts (removed in step 4) so that the TV cannot be accidentally removed from the mount.





HEAVY! You may need assistance with this step.



Step 7

Final Adjustments

- The screens can be tilted $+8^{\circ}$ to -18° , leveled $\pm 3^{\circ}$, and can swivel 360° .
- Tightening the bolt on the Swivel Bracket will prevent 360° rotation. Loosening the bolt will allow 360° rotation.



Visit us at www.mount-it.com for product registration and warranty information.

Our US based customer service team is standing by to answer any questions you have about your Mount-It! product.

Available by phone **Monday - Friday from 5:00AM-5:00PM PST.**

Chat live with an agent on our website!



support@mount-it.com



(855) 925-5668



www.mount-it.com