


MOUNT-IT!

Installation Manual

SKU: MI-604

SKU: MI-604W



Please scan this QR code
to visit the product page.

PROJECTOR CEILING & WALL MOUNT



HAVE QUESTIONS?

Monday - Friday from 8:00am - 4:00pm PST



support@mount-it.com



(855) 925-5668



www.mount-it.com

Thank you for choosing Mount-It!

EN Read the entire instruction manual before you start installation and assembly. If you have any questions regarding any of the instructions or warnings, please contact Mount-It! for assistance.



- CAUTION:** Use with products heavier than the rated weights indicated may result in instability causing possible injury.
- Please closely follow the assembly instructions. Improper installation may result in damage or serious personal injury.
 - Safety gear and proper tools must be used. This product should only be installed by professionals.
 - This product is designed to be installed on solid concrete walls, masonry walls or wood stud walls.
 - Make sure that the supporting surface will safely support the combined weight of the equipment and all attached hardware and components.
 - Use the mounting screws provided and DO NOT OVER TIGHTEN mounting screws.
 - This product contains small items that could be a choking hazard if swallowed. Keep these items away from children.
 - This product is intended for indoor use only. Using this product outdoors could lead to product failure and personal injury.
- IMPORTANT:** Ensure that you have received all parts according to the component checklist prior to installation. If any parts are missing or faulty, contact Mount-It! for a replacement.

MAINTENANCE: Check that the product is secure and safe to use at regular intervals (at least every three months).

DE Lesen Sie die gesamte Bedienungsanleitung, bevor Sie mit der Installation und Montage beginnen. Wenn Sie Fragen zur Anleitung oder Warnungen haben, wenden Sie sich bitte an Ihren örtlichen Händler.



- VORSICHT:** Die Verwendung mit Produkten, die schwerer als die angegebenen Nenngewichte sind, kann zu Instabilität führen und zu möglichen Verletzungen führen.
- Bitte befolgen Sie die Montageanleitung genau. Eine unsachgemäße Installation kann zu Schäden oder schweren Verletzungen führen.
 - Sicherheitsausrüstung und geeignete Werkzeuge müssen verwendet werden. Dieses Produkt sollte nur von Fachleuten installiert werden.
 - Dieses Produkt ist auf massiven Betonwänden oder Mauerwerkswänden zu montieren.
 - Stellen Sie sicher, dass die Auflagefläche des Gesamtgewichts des Geräts und aller angeschlossenen Hardware und Komponenten sicher trägt.
 - Verwenden Sie die mitgelieferten Befestigungsschrauben und die Befestigungsschrauben NICHT ZU FEST ANZIEHEN.
 - Dieses Produkt enthält Kleinteile, die beim Verschlucken eine Erstickungsgefahr darstellen können. Halten Sie diese Gegenstände von Kindern fern.
 - Dieses Produkt ist nur für den Innenbereich bestimmt. Die Verwendung dieses Produkts im Freien kann zu Produktversagen und Verletzungen führen.
- WICHTIG:** Stellen Sie vor der Installation sicher, dass Sie alle Teile gemäß der Komponenten-Checkliste erhalten haben. Bei beschädigten oder fehlenden Teilen, wenden Sie sich an Ihre Verkaufsstelle, um Ersatz zu erhalten.
- WARTUNG:** Überprüfen Sie das Produkt in regelmäßigen Abständen auf Sicherheit und Stabilität (am besten alle drei Monate).

FR Lisez entièrement le guide d'utilisateur avant de commencer l'installation et le montage. Si vous avez des questions concernant les instructions ou les avertissements, veuillez contacter votre distributeur local pour une assistance.



- ATTENTION:** L'utilisation de produits plus lourds que les poids nominaux indiqués peut entraîner une instabilité causant des blessures potentielles.
- Les supports doivent être joints comme spécifié dans les instructions de montage. Une mauvaise installation peut entraîner des dommages ou de graves blessures aux personnes.
 - Un équipement de sécurité et les outils appropriés doivent être utilisés. Ce produit devrait être installé uniquement par des professionnels.
 - Ce produit est conçu pour être installé sur des murs avec poteaux en bois, des murs en béton massif ou murs en brique.
 - Assurez-vous que la surface de soutien supporte le poids combiné de l'équipement et de tous les matériaux et composants associés.
 - Utilisez les vis de montage fournies et NE SERREZ PAS TROP les vis de montage.
 - Ce produit contient de petites pièces qui peuvent causer un étouffement si elles sont avalées. Éloignez ces pièces des enfants.
 - Ce produit est prévu uniquement pour une utilisation à l'intérieur. L'utilisation de ce produit à l'extérieur peut entraîner une défaillance du produit ou des blessures aux personnes.
- IMPORTANT:** Avant l'installation, assurez-vous que vous avez reçu toutes les pièces selon la liste de vérification des composants. Si une pièce est manquante ou endommagée, téléphonez à votre distributeur local pour qu'il la remplace.
- MAINTENANCE:** A intervalles réguliers (au moins tous les trois mois) vérifiez que le support est d'utilisation sûre et fiable.

RU Перед началом установки и сборки прочитайте руководство по установке. Если у Вас возникли какие-либо вопросы относительно инструкции или предупреждений, свяжитесь с Вашим местным распространителем для получения помощи.



- ВНИМАНИЕ:** Использование продуктов, вес которых превышает указанный расчетный вес, может привести к неустойчивости и возможным травмам.
- Опоры должны быть установлены, как это показано в монтажных инструкциях. Неправильная установка может привести к получению серьезных травм.
 - Необходимо использовать предохранительное устройство и специальные инструменты. Продукт должен устанавливаться только профессионалами.
 - Продукт предназначен для установки на деревянные каркасные стены, твердые цементные стены или кирпичные стены.
 - Убедитесь, что несущая поверхность выдержит вес всего установленного оборудования и комплектующих.
 - Необходимо использовать монтажные винты, входящие в комплект поставки, и НЕ ПЕРЕТЯГИВАТЬ монтажные винты.
 - Данный продукт содержит мелкие детали, которые представляют опасность удушья при проглатывании. Такие детали необходимо хранить в недоступном для детей месте.
 - Данный продукт предназначен только для эксплуатации в помещениях. Использование данного продукта на улице может привести к поломке продукта и получению травм.
- ВАЖНО:** Перед установкой убедитесь, что Вы получили все детали в соответствии со списком комплектующих. Если не хватает каких-либо деталей или они поломаны, свяжитесь с Вашим местным распространителем по вопросу замены.
- ТЕХНИЧЕСКОЕ ОБСЛУЖИВАНИЕ:** Необходимо регулярно проверять (как минимум, раз в три месяца), чтобы кронштейн был зафиксирован, и его использование было безопасным.

ES Lea todo el manual de instrucciones antes de comenzar la instalación y ensamble de la unidad. Si tiene alguna inquietud con respecto a las instrucciones o advertencias, comuníquese con su distribuidor local.



- PRECAUCIÓN:** utilizar con productos de mayor peso al indicado en los límites de peso podría ocasionar inestabilidad y posibles heridas personales.
- Los soportes deben acoplarse tal como se indica en las instrucciones de ensamble. Una incorrecta instalación podría ocasionar daños y serias heridas personales.
 - Utilice las herramientas y equipo de seguridad adecuados. Este producto solo debe ser instalado por profesionales.
 - Este producto está diseñado para instalaciones en paredes de madera sólida, concreto sólido o bloques.
 - Asegúrese de que la superficie de fijación sostenga de manera segura el peso total del equipo y todos sus componentes y hardware.
 - Utilice los tornillos de ensamble suministrados y NO aplique demasiada tensión a los tornillos.
 - Este producto contiene piezas pequeñas que representan un riesgo de asfixia. Mantenga estas piezas fuera del alcance de los niños.
 - Este producto está diseñado para uso en interiores solamente. Utilizar este producto en exteriores podría ocasionar fallas y heridas personales.
- IMPORTANTE:** Asegúrese de que haya recibido todas las piezas según la lista de verificación de componentes para la instalación. Si falta alguna de las partes, o está dañada, comuníquese con su distribuidor.
- MANUTENIMIENTO:** Compruebe periódicamente que el soporte esté asegurado y listo para usar (al menos cada tres meses).


PT Leia todo o manual de instruções antes de iniciar a instalação e montagem. Se você tiver alguma dúvida sobre quaisquer uma das instruções ou avisos, por favor, entre em contato com o seu distribuidor local para assistência.




- ATENÇÃO:** O uso com produtos mais pesados do que os pesos indicados pode resultar em instabilidade, causando possíveis danos.
- Os suportes devem ser anexados como especificado nas instruções de montagem. A instalação incorreta pode causar danos ou sérias lesões pessoais.
 - Equipamentos de segurança e ferramentas adequadas devem ser utilizadas. Este produto só deve ser instalado por profissionais.
 - Este produto é projetado para ser instalado em paredes verticais de paredes de madeira, paredes de concreto sólido ou de tijolos.
 - Certifique-se que a superfície de suporte suportará com segurança o peso combinado do equipamento e todas as ferragens e componentes anexados.
 - Use os parafusos de montagem fornecidos e NÃO APERTE EXCESSIVAMENTE os mesmos.
 - Este produto contém pequenas peças que podem causar asfixia se ingeridas. Mantenha esses itens longe do alcance de crianças.
 - Este produto destina-se somente para uso interno. Usá-lo em ambiente externo pode causar falhas no produto e lesões pessoais.
- IMPORTANTE:** Assegure-se que você recebeu todas as peças, de acordo com a lista de componentes, antes da instalação. Se alguma peça estiver faltando ou é defeituosa, contate o seu distribuidor local para substituição.
- MANUTENÇÃO:** Certifique-se que o suporte seja seguro e protegido para o uso em intervalos regulares (pelo menos a cada três meses).



Mount and Accessories



Mounting Hardware




Check carefully to make sure there are no missing or defective parts. Some hardware provided may not be used. Use the correct mounting hardware suitable for your installation.

CHOKING HAZARD. Package includes small parts.
Not for children under 3 years. Adult supervision is required.

Missing Parts? Call us at (855) 925-5668 and we will ship replacement parts free of charge.

DIMENSIONS & WEIGHT CAPACITY



Rated weight capacity is 44lbs for the mount.


Caution:

Ensure all mounting surfaces are capable of holding the weight of your mount.

DO NOT EXCEED MAXIMUM LISTED WEIGHT CAPACITY. SERIOUS INJURY OR PROPERTY DAMAGE MAY OCCUR!

Insert A/V Cable Through the Mount Arm

- Before beginning it is recommended that you run any A/V, power, or other cables through the Mount Arm (#B) at this time.




Step 1

Ceiling Mount Configuration

- Connect the Ceiling Bracket (#A) to the top of the Mount Arm (#B) using Bolts (#M-B) Washers (#M-J) and tightening until secure with Hex Wrench (#M-L).

Note: If you will be installing the mount on the wall proceed to step 2c-1


- Connect the Arm Joint (#C) to the bottom of the Mount Arm (#B) using Bolts (#M-A) Washers (#M-H) and tightening until secure with Hex Wrench (#M-K).



Step 2a-1

Ceiling Solid Wood Installation Option


- Hold the assembled arm to the desired location and use a pencil to mark the center of the 4 holes in the bracket.
- Using a 3/16" drill bit, drill holes in the marked locations to a depth of 2.2".
- Attach the mount using Lag Screws (#W-A) and Washers (#W-C) tighten all screws until secure.



Step 2a-2

Attach the Projector


- To connect your projector to the Projector Bracket (#B) select the appropriate size mounting bolt (Select one size #M-C, M-D or M-E) and washer (#M-F, M-G, M-H) for your projector's mounting holes and verify the length of the bolt is not too long. If you are unsure of the correct bolt size refer to your projector's user manual or contact the manufacturer for sizing information.
- Position the angle of each arm to align the holes on the bracket and projector by extending or retracting the length of the arms. Depending on the configuration of the mounting holes it may be necessary to use adapters(#M-M) to properly fit your projector.



Step 2a-3

Hang the Projector on the Mount Arm


- Connect the projector to the rest of the mount by hanging the projector bracket on the mount arm as shown here. Ensure that the bracket is fully seated in the end of the L shaped channel so that it cannot slide off when released. Secure it in place using Bolts (#M-A) Washers (#M-H) and Plastic Washer (#M-I) as shown in the magnification bubble.
- Adjust the height of the Mount Arm as needed by sliding the telescoping arm up or down. To adjust, loosen the bolt as shown with Hex Wrench (#M-L) slide to the desired position and lock in place by tightening the screw again.



Step 2a-4

Final Adjustments


- The projector may be leveled 8 degrees in each direction and tilted 15 degrees up or down by adjusting the bolts shown in the magnification bubbles. If desired the Cable Management Cover (#E) can be cut to size and placed as shown to cover the cable management channel.



Step 2b-1

Ceiling Concrete/Stone Installation Option


- Hold the assembled arm to the desired location and use a pencil to mark the center of the 4 holes in the bracket.
- Using a 3/8" drill bit, drill holes in the marked locations to a depth of 2.4". Note: Do not drill mounting holes into mortar (such as between bricks or stones) only drill and install into solid stone or concrete surfaces.
- Insert the Concrete Anchors into the holes, then attach the mount using Lag Screws (#W-A) and Washers (#W-C) tighten all screws until secure.



Step 2b-2

Attach the Projector


- To connect your projector to the Projector Bracket (#B) select the appropriate size mounting bolt (Select one size #M-C, M-D or M-E) and washer (#M-F, M-G, M-H) for your projector's mounting holes and verify the length of the bolt is not too long. If you are unsure of the correct bolt size refer to your projector's user manual or contact the manufacturer for sizing information.
- Position the angle of each arm to align the holes on the bracket and projector by extending or retracting the length of the arms. Depending on the configuration of the mounting holes it may be necessary to use adapters (#M-M) to properly fit your projector.



Step 2b-3

Hang the Projector on the Mount Arm


- Connect the projector to the rest of the mount by hanging the projector bracket on the mount arm as shown here. Ensure that the bracket is fully seated in the end of the L shaped channel so that it cannot slide off when released. Secure it in place using Bolts (#M-A) Washers (#M-H) and Plastic Washer (#M-I) as shown in the magnification bubble.
- Adjust the height of the Mount Arm as needed by sliding the telescoping arm up or down. To adjust, loosen the bolt as shown with Hex Wrench (#M-L) slide to the desired position and lock in place by tightening the screw again.



Step 2b-4


Final Adjustments

- The projector may be leveled 8 degrees in each direction and tilted 15 degrees up or down by adjusting the bolts shown in the magnification bubbles. If desired the Cable Management Cover (#E) can be cut to size and placed as shown to cover the cable management channel.



Step 2c-1

Connect the Arm Brackets for Wall Installation





- Connect the Arm Joint (#C) to the end of the Mount Arm (#B) using Bolts (#M-A) Washers (#M-H) and tightening until secure with Hex Wrench (#M-K)

Step 2c-2

Wall Concrete/Stone Installation


- Hold the assembled arm to the desired location and use a pencil to mark the center of the 4 holes in the bracket.
- Using a 3/8" drill bit, drill holes in the marked locations to a depth of 2.4". Note: Do not drill mounting holes into mortar (such as between bricks or stones) only drill and install into solid stone or concrete surfaces.
- Insert the Concrete Anchors into the holes, then attach the mount using Lag Screws (#W-A) and Washers (#W-C) tighten all screws until secure.



Step 2c-3

Attach the Projector


- To connect your projector to the Projector Bracket (#B) select the appropriate size mounting bolt (Select one size #M-C, M-D or M-E) and washer (#M-F, M-G, M-H) for your projector's mounting holes and verify the length of the bolt is not too long. If you are unsure of the correct bolt size refer to your projector's user manual or contact the manufacturer for sizing information.
- Position the angle of each arm to align the holes on the bracket and projector by extending or retracting the length of the arms. Depending on the configuration of the mounting holes it may be necessary to use adapters (#M-M) to properly fit your projector.



Step 2c-4

Hang the Projector on the Mount Arm


- Connect the projector to the rest of the mount by first hanging the projector bracket on the mount arm as shown here. Ensure that the bracket is fully seated in the end of the L shaped channel so that it cannot slide off when released. Secure it in place using Bolts (#M-A) Washers (#M-H) and Rubber Gasket (#M-I) as shown in the magnification bubble.
- Adjust the length of the Mount Arm as needed by sliding the telescoping arm forward or back. To adjust, loosen the bolt as shown with Hex Wrench (#M-L) slide to the desired position and lock in place by tightening the screw again.



Step 2c-5

Final Adjustments

- The projector may be leveled 8 degrees in each direction and tilted 15 degrees up or down by adjusting the bolts shown in the magnification bubbles. If desired the Cable Management Cover (#E) can be cut to size and placed as shown to cover the cable management channel.



Visit us at **www.mount-it.com** for product registration and warranty information.

Our US based customer service team is standing by to answer any questions you have about your Mount-It! product.

Available by phone **Monday - Friday from 8:00am to 4:00pm** PST.

Chat live with an agent on our website!



support@mount-it.com



(855) 925-5668



www.mount-it.com