CLEANING

CAUTION: never use any abrasive, corrosive or scouring cleaning agents. Such agents might damage the truck.

• You may clean the stair climbing hand truck with a damp cloth. Allow it to dry afterwards.

TECHNICAL DATA

Dimensions when folded down 45 x 48 x 100 cm
Dimensions when folded up 39 x 9 x 63.5 cm
Dimension of loading area 39 x 28 cm
Weight 4.1 kg
Steps: min. width / max. height 60 cm / 22 cm
Maximum load-bearing capacity 70 kg on level ground
35 kg on stairs

WARNING

This product is not a toy. Do not allow children to play with or near this item. Do not exceed weight capacity. **Be aware of dynamic loading!**

Sudden load movement may briefly create excess load causing product failure. Use as intended only. Inspect before every use; do not use if parts are loose or damaged.



Flat Ground



Stairs

Thank you for choosing Mount-It!

Visit us at **www.mount-it.com** for product registration and warranty information.

Our US based customer service team is standing by to answer any questions you have about your Mount-It! product.

Available by phone **Monday - Friday from 8:00am to 4:00pm** PST.

Chat live with an agent on our website!


support@mount-it.com

(855) 915-2666

www.mount-it.com

MOUNT-IT!

User Manual
SKU: MI-953



STAIR CLIMBER HAND TRUCK

HAVE QUESTIONS?

Monday - Friday from 8:00am - 4:00pm PST

support@mount-it.com

(855) 915-2666

www.mount-it.com

Thank you for purchasing our product. We hope you enjoy the stair climbing hand truck.
Please always keep these operating instructions within easy reach. Observe all operating and safety instructions. If you ever sell or share this truck with others, also hand over these operating instructions since they are an integral part of the product.

INSTRUCTIONS FOR YOUR SAFETY

Please read these safety instructions carefully before you use the product for the first time!

• Dispose of unused packaging material or store it in a place inaccessible for children. There is a risk of suffocation!
• Before using this product, make sure that you understand all instructions in order to avoid accidents.
• Operate the stair climbing hand truck on stairs only if you feel absolutely fit and healthy.
• Do not overload the stair climbing hand truck!
• Avoid tilting the truck when loaded to prevent it from tipping over.
• Secure the load on the stair climbing hand truck.
• Always move the stair climbing hand truck over obstacles at right angles, i.e. with the wheels on both sides in contact with the ground.
• The stair climbing hand truck is not suited for markedly spiral or spacesaving staircases and is totally unsuited for open stairways.
• Park the stair climbing hand truck on level and firm surfaces and additionally secure the truck against rolling away.
• Before using the stair climbing hand truck, check all parts and safeguards for proper and tight fit. Never use the truck when damaged.
• Persons with limited physical, sensory or mental capabilities must not use the stair climbing hand truck.
• Never allow children to operate the stair climbing hand truck. The truck is not a toy.
• Do not use the stair climbing hand truck on sandy soil or other soft, loose surfaces.
• The stair climbing hand truck is not suited for carrying people or animals.
• Always store the stair climbing hand truck in a dry and well-ventilated place.
• The construction of the stair climbing hand truck must not be altered.
• Use only spare parts and accessories supplied or approved by us.


INTENDED USE

The stair climbing hand truck is intended for private use only and must not be used for industrial or commercial purposes.

Please note that improper use will lead to the forfeiture of liability claims.

PACKAGE CONTENTS


Assembly Time:
Less than 10 minutes



(A) Hand Truck


(B) Long Bolts x4


(C) Short Bolts x4



(D) Nuts x8


(E) Casters x4



(F) Bungee Cord

Missing Parts?
Call us at (855) 925-5668 and we will ship replacement parts free of charge.

TOOLS REQUIRED (NOT INCLUDED)



CASTER WHEELS INSTALLATION (OPTIONAL)



Note: The installation of the provided Casters (E) are optional and available for those who desire the functionality provided by installing pivoting wheels beneath the nose plate.

To install the wheels to the bottom of the nose plate, use the provided Nuts (D) and Bolts (B,C). The Long Bolts (B) will be used for the 2 Casters closest to the hand truck body, while the Short Bolts (C) will be used for the 2 casters farthest from the hand truck body.

Secure the Bolts in place using Nuts (D) and tighten until secure.

FOLDING DOWN

Figure A
To unfold the hand truck, grab the end of the nose plate with one hand and the handle or body of the hand truck with the other. Pull the nose plate down and away from the center of the hand truck until it is fully lowered, and the wheels will fold away from the body to be perpendicular to the hand truck body.

Figure B
The hand truck comes with a dual handle. Release the handle from its locked position by squeezing the lower handle against the higher handle, then pull both handles up until the desired height is reached. Note: There are multiple height settings for the handle, and you may need to hold down the lower handle or press it in again to reach the full extension.

Figure A





Figure B



FOLDING UP

Figure C
To fold the hand truck for storage or transport begin by lowering the handle to the lowest position. It can be lowered by squeezing the squeezing the lower handle against the higher handle, then lower it until it has reached the lowest setting.

Figure D
Fold the nose plate up by grabbing the end of the nose plate with one hand and the handle or body of the hand truck with the other. Pull the nose plate up and toward the center of the hand truck until it has fully raised and parallel to the handle. Ensure the wheels are fully folded back against the hand truck.

Figure C





Figure D



LOADING

• Always load heavy objects first.
• Observe the maximum load-bearing capacity indicated in the technical data section.
• Always ensure that you stand securely on the stairs and wear sturdy and slip-resistant shoes.