




Supplied Parts List



(1) 35mm Tube Support-a




(1) Disconnected "C" Clamp-b




(1) VESA Plate with Arm Assembled-c




(1)Wrench-p




(4)M4x12 Thumb Bolt-d




(4)M4x30 Bolt-e



(8)M4 Washer-f



(4)M4 Space-g




(2)Wire Clip-h




(2)M10x15 Bolt-i



(1)Allen Key-j



(2)Spare Plastic Cover-k



(1)Laptop Tray-l



(4)M4x10 Bolt-m



(4)M4 Washer-n



(4)M4 Nut-o

Tools Required

Phillips Screwdriver



WARNING


CAUTION!

This monitor desktop mount must be securely attached to the horizontal desk. If the mount is not properly installed it may fall, resulting in possible injury and/or damage.

Step 1

Install the “C” Clamp According to the Desktop Thickness


The depth of “C” clamp can be changed in three positions. Choose the proper depth according to the thickness of your desktop. Connect it by 2pcs M10x15 bolts(i), using the supplied Allen Key(j).



Step 2


Install Arm to the Tube Support

Install arm to the tube support, please make sure the wire clip in the downside. Fasten the bolt by supplied Allen Key(j).




Step 3


Mount the Laptop Tray/Monitor to VESA Plate



For Laptop





For Flat Back Monitor



For Curved Back Monitor


Step 4

Adjust the Height and Install the Wire Clips




Step 5

Do Necessary Adjusting



Fix the tilt angle
Remove the plastic cover, tighten the nut by the Wrench(p) to fix the tilt angle.



Remove the plastic cover, use the Allen Key(j) to do the necessary adjustment.